
SEZNAM PŘÍSLUŠENSTVÍ

Reakční tréninková lampa
Nabíjecí kabel USB 4v1
Magnetická fólie s lepidlem
Organizér
Dálkový ovladač
Návod k instalaci

ZPŮSOB INSTALACE

1. Položte naplocho na libovolnou rovinu.
2. Přilepte železný kus s lepidlem na jakoukoli stěnu/rovný povrch a poté na něj přisaďte reakční světlo.
3. Reakční světlo se připevňuje na magneticky připevnitelné kovové panely/stojany na fitness strojích/dveřích ledničky atd.

Popis tlačítek dálkového ovladače



POUŽITÍ



1. Zapnutí reakčního světla: Dlouhým stisknutím červeného tlačítka napájení na boku zapnete a vypnete reakční světlo.
2. Zapnutí dálkového ovladače: Dlouhým stisknutím tlačítka napájení zapnete a vypnete dálkové ovládání.
3. Připojení reakčních světel: Klikněte na tlačítko připojení dálkového ovladače. Kontrolka dálkového ovladače bliká modře, když je dálkové ovládání připojeno.
Pokud kontrolka nesvítí, připojení je úspěšné.
Pokud kontrolka svítí zeleně, všechny reakční světla jsou připojena.
4. Výběr tréninkového režimu: Na dálkovém ovladači jsou čtyři tréninkové režimy, které odpovídají režimu výběru tlačítek.
Opětovným stisknutím tlačítka napájení dálkového ovladače spusťte trénink reakce.
5. Přepínání barev reakčního světla: Během používání lze cílové světlo ručně a dočasně upravit stisknutím tlačítka pro přepínání barev.
Každé stisknutí změní barvu cílového světla.
K dispozici celkem 7 barev.

POPIS REŽIMU

1. Sekvenční režim: Pokaždé se reakční kontrolka rozsvítí podle čísla kontrolky, od malé po velkou, a cyklus se opakuje.
2. Náhodný režim: Pokaždé se náhodně rozsvítí jedno světlo a barva světla je pokaždé náhodná.
3. Režim kyvadlového běhu: Pokaždé, když se jako první rozsvítí reakční kontrolka s nejnižším číslem a poté, co ji uživatel zhasne, se příště náhodně rozsvítí jakékoli jiné světlo s číslem a opakuje se to.
4. Nalezení různých režimů: Všechna světla svítí a uživatel musí vypnout světla různých barev.
Pokaždé se rozsvítí jedno světlo, jehož barva se liší od ostatních světel (barva bude pokaždé náhodná).

DALŠÍ POZNÁMKY

1. Po zapnutí dálkového ovladače stiskněte tlačítko „Připojit" pro připojení reakčního světla.
2. Vzdálenost mezi dálkovým ovladačem a reakční plochou by měla být do 10 metrů.
3. Pokud je spojení mezi reaktivními světly a dálkovým ovládáním přerušeno z důvodu výpadku napájení dálkového ovládání, dálkové ovládání je příliš daleko od reaktivních světel nebo se jednotlivé lampy omylem vypnou/odpojí od napájení, stačí zapnout vypnuté lampy/dálkové ovládání (v případě přerušení není třeba restartovat) a znovu stisknout tlačítko připojení dálkového ovládání a dálkové ovládání všechny lampy znovu propojí.
4. Popis barvy kontrolky dálkového ovladače.
Probíhající kontrolka reakce na připojení: modrá
Připojení dokončeno: zelená
Náhodný režim: zelená
Sprint vpřed a vzad: fialová
Hledejte rozdíly: modrá
Náhodnost: červená
Svítí bílé světlo, což znamená, že zařízení funguje, a můžete náhodně přepínat režimy.
Po přepnutí režimu je nutné znovu kliknout na tlačítko zapnout/vypnout.
5. Barva v pohotovostním režimu:růžová (dlouhotrvající jasná), výška snímání: 10cm
6. Po 2 hodinách nabíjení lze zařízení používat 15 hodin.
Pokud je reakční světlo zapnuté a 10 minut není připojeno, automaticky se vypne.
Během nabíjení není reakční světlo k dispozici.
Kontrolka nabíjení se rozsvítí červeně a po plném nabití se rozsvítí zeleně a zařízení se automaticky vypne.
7. Výrobek by neměl být vystaven násilným nárazům ani šlapání, umístěte jej prosím na bezpečné místo pro použití.


LIST OF ACCESSORIES

reaction training lamp
4-in-1 USB Charging Cable
Adhesive Backed Magnetic Sheet
organizer bag
remote control
instructions


INSTALLATION METHOD

1.lie flat on an arbitrary plane
2.Glue the adhesive backed iron piece to any wall/flat surface and then suck the reaction light onto the iron piece.
3.Reaction light attaches to magnetically attachable metal panels/stands on fitness equipment/refrigerator doors, etc.

Remote Control Button Description



USAGE



1.Turn on the reaction light: Long press the black power button on the side to turn on and off the reaction light.
2.Remote control power on: Long press the power button to turn on and off the remote control
3.Connecting reaction lamps: Click the remote control connection button, the remote control indicator light blinks blue when the remote control is in the connection state, the light is off means the connection is successful, the remote control indicator light is green means all reaction lamps are connected.
4.Training mode selection: There are four training modes on the re mote control,corresponding to the button selection mode.Press the remote control power button again to start the reaction training.
5.Reaction light color switching: During use, the target light can be manually and temporarily adjusted by pressing the color switching button. Each press changes the color of the target light, and there are a total of 7 colors to choose from

MODE DESCRIPTION

1. Sequential mode: each time the reaction lamp will be lit according to the lamp number number, from small to large and repeat the cycle
2. Random mode: Each time one light is randomly lit, and the color of the light is random each time.
3. Shuttle run mode: Each time the lowest numbered reaction light is lit first, and after the user taps it off, the next time any other numbered light is randomly lit, and it keeps repeating.
4. Find different modes: All lights are on, and the user needs to turn off the lights of different colors. Each time, there will be one light whose color is different from the other lights (the color will be random each time it lights up).

OTHER NOTES

1.After the remote control is turned on, press the Connect button to connect the reaction light
2.The distance between the remote control and the reaction light should be controlled within 10 meters
3.If the connection between the reactive lamps and the remote control is interrupted due to power failure of the remote control the remote control is too far away from the reactive lamps, or the individual lamps are turned off/out of power by mistake just turn on the turned off lamps/remote control (no need to reboot in the case of disconnection) and press the remote control connection button again, and the remote control will reconnect all the lamps again.
4.Remote control indicator light color description.
Connection reaction light in progress: blue
Connection completed: green
Randomized mode: green
sprinting backwardsand forwards： purple
look for differences： blue
randomization： red
The white light is on, which means it is working, and you can switch the mode randomly, and you need to click the on/off button again after switching the mode.
5.Standby color: pink (long bright), sensing height: 10CM
6.Charging for 2 hours, it can be used for 15 hours. If the reaction light is turned on and not connected for 10 minutes, it will automatically shut down. The reaction light is not available during the charging process. The charging light will turn red, and when fully charged, it will turn green and automatically shut down
7.The product should not be violently struck or stepped on, please place it in a safe place for use.

Dodavatel: RADANSPORT s.r.o.
Za Otýlií 10
České Budějovice, 370 01
The Czech Republic

e-sportshop.com